


# LASER LEVEL

Manual in English



#### Contents

#### Congratulations!


You have chosen one of our laser level that's guaranteed reliable and tough for professional tool users at various job sites.

- SAFETY
- SPECIFICATION
- PRODUCT OVERVIEW
- OPERATING
- MAINTENANCE
- WARRANTY

## SAFETY

- Read the Safety Instruction and Manual thoroughly before using this product. All users must fully understand and adhere to these instructions.
- While the product is in operation, be careful not to expose your eyes to the emitting laser beam (red light source). Exposure to a laser beam for an extended time may be hazardous to your eyes.
- Do not stare directly into the beam or view directly with optical instruments or set up the laser at eye level.
- Do not disassemble the laser tool. There are no user serviceable parts inside.
- Do not modify the laser in any way. Modifying the tool may result in hazardous Laser Radiation Exposure.
- Do not operate the laser around children or allow children to operate the laser.
- An exposure to the beam of a Class 2 laser is considered safe for a maximum of 0.25 seconds. Eyelid reflexes will normally provide adequate protection.

## PRODUCT OVERVIEW



- 2 Vertical Laser window
- Lock switch

- 5.360°Light cone
- 6.1/4"adapter screw hole

Version:T56 20230906

-1-

# SPECIFICATION

Laser Class	Class II
Laser Wavelength	505~550nm for Green beam
Leveling Accuracy	±1.5mm/5m
Leveling/Compensation Range	4°±1°
Working Distance (Line)	30m for Green beam
Operating Time	7h
Power Source	2*1.5V AA
IP Rating	IP54
Operation Temperature Range	-10℃~+50℃
Storage Temperature Range	-25℃~+70℃

# OPERATING

Keep the lock switch at " position during moving the laser level or storage it.

↑↑ It is very important!

#### 1.Self-leveling mode

When the lock switch slides to the " position, the instrument will unlock and light up all laser lines, and the instrument will automatically level and the indicator light will be green. (If the indicator is red and the laser flashes frequently, it indicates uneven light. Please place the laser level on a flatter place, because the automatic leveling range is about 4°)

\* short press the power key, the brightness of the light can be adjusted, the brightness is divided into 4 levels, and the key cycle. \* long-press the power key, the pulse mode is turning on, The induction light blinks green, and the module light dimms. long-press again to return to normal mode. In this mode, energy saving mode is invalid.

#### 2.Locked mode:

When the lock switch is set to " , long press the power key, all the laser lines are on, flashing every 5 seconds, and the indicator liaht is red.

\* short press the power key, the brightness of the light can be adjusted, the brightness is divided into 4 levels, Short press the brightness cycle, in which case you can tilt the level arbitrarily. \* long-press the power key, turn off the laser level.

Note: If the indicator is red and blinking frequently, it indicates that the batterv is weak and needs to be replaced.

# MAINTENANCE

- The laser instrument has been strictly calibrated and packaged in the factory according to various precision indexes.
- Accuracy checks are recommended before first use and periodically in the future, especially in environments where high accuracy is required.
- Do not store laser tools in direct sunlight or expose them to high temperatures. The shell and some internal parts are made of plastic and may deform under high temperatures.
- Clean the external plastic parts with a damp cloth. Solvents should never be used, even if these parts have some solubility. Use a soft dry cloth to remove moisture before storing.
- Do not dispose of this product with household waste.

# WARRANTY

- 1. We provide one year warranty on the Laser Distance Meter from the date of purchase.
- 2. The warranty card must be provided when the instrument is under warranty, and the invoice shall be provided.
- 3. Please contact your local dealer for repair or replacement Disclaimer

The following conditions without warranty:

- Unauthorized disassemble of instruments
- II Wrong operating or man-made damage to the instrument.
- III Did not use the original accessories and cause damage.
- IV Give the instrument to unauthorized person or unit for repair.
- V Product serial number was deleted